

MAXIM[®]

Hi-Q Disinfectant

Features:

Hospital-use disinfectant

Deodorizes

Concentrated

Description

A concentrated hospital-use disinfectant that is effective against a broad-spectrum of bacteria and is virucidal*. This product can be used on hard, non-porous surfaces such as: aluminum, brass, copper, glass surfaces, laminated surfaces, metal, stainless steel, glazed porcelain, sealed stone, Plexiglas®, enameled surfaces, painted woodwork, Formica®, vinyl and plastic upholstery, finished floors, walls, tables, and chairs.

Directions

FOR USE AS A GENERAL, HOSPITAL, MEDICAL DISINFECTANT, VIRUCIDE*, CLEANER:

- ① Pre-clean visibly soiled areas.
- ② Apply use solution of 0.5 oz. of this product per gal. of water to disinfect hard, non-porous surfaces with a sponge, brush, cloth, mop, by immersion, auto scrubber, mechanical spray device. For spray applications, spray 6-8 inches from surface. Do not breathe spray.
- ③ Treated surfaces must remain visibly wet for 2 minutes to kill SARS-CoV-2 and 10 minutes to kill all organisms listed on the label. Rinse with potable water after use on surfaces that come in contact with food.
- ④ Allow to air dry. Rinsing of floors is not necessary unless they are to be waxed or polished.
- ⑤ Prepare a fresh solution daily or when visibly dirty.



Applications

This product is for use in:

- > Hospitals
- > Public restrooms
- > Schools

Specifications

Color	Blue
Fragrance	Floral
pH Range	6.0 - 6.5
Dilution	1/2 oz./gal.
Density	8.42

Packaging

4/1 gallon	047300-41
------------	-----------

Product Registration No.

EPA: 10324-108-45745

J21